



Necessary preparations before installing a 2-group La Marzocco coffee machine in Switzerland

(!! NOT 3-Groups!!)

Attention:

- Please do *not* plan the installation simultaneously with the plumber, electrician or carpenter: we only hook up to finished connections ready to plug in.
- Avoid installations during the construction phase to protect the machine.
- Tick all the boxes with the construction supervisor and inform us 48h before the installation if anything is not ready!
- Water must be running and all sockets powered!
- In case of unexpected delays, we will have to charge additional costs

Installatio	n-	Height = full counter height (800mm) Width = min. 400mm	Directly underneath the machine for sockets ①, water in- ② and outlet ③, pump and water-filter
compartm	ent	Depth = full counter depth (600mm)	
Holo in	table	oton directly to the	Diameter ∅ 80 mm
Hole in tabletop directly to the installation compartment (for water pipes and cables)			Centered underneath the machine
① Sockets	1>	t type 15 socket for coffee machine (3 x 400V/10A,3P,N +E)	
	1 p	ug-in slot type 13 socket <mark>per</mark> grinder	• • •
② Water inlet		3/8" fresh water line with stopcock. d fresh water with at least 3 bar line pressure	
③ Water outlet	4	1x <u>open</u> syphon with at least 0 mm diameter and 150 mm riser	

Visualization

