



Necessary preparations before installing a Rocket gastronomy coffee machine in Switzerland

Attention:

- Please do *not* plan the installation simultaneously with the plumber, electrician or carpenter: we only hook up to finished connections ready to plug in.
- Avoid installations during the construction phase to protect the machine.
- Tick all the boxes with the construction supervisor and inform us 48h before the installation if anything is not ready!
- Water must be running and all sockets powered!
- In case of unexpected delays, we will have to charge additional costs.

Installatio	nent	Height = full counter height (800mm)	<u>Directly underneath</u> the	
		Width = min. 400mm	machine for sockets ①, water in- ② and outlet ③,	
compartme	ent	Depth = full counter depth (600mm)	and water-filter	
Hole in	tahl	eton directly to the	Diameter Ø 80 mm	
Hole in tabletop directly to the		Diameter 2 80 mm		
		on compartment	Centered underneath the	
(1	for wat	er pipes and cables)	machine	
① Sockets		(type 25 socket for coffee machine (3 x 400V/16A,3P,N +E)		
② Water inlet	1x	3/8" fresh water line with stopcock. d fresh water with at least 3 bar line pressure		
③ Water outlet	4	1x <u>open</u> syphon with at least 10 mm diameter and 150 mm riser		

Visualization

