

La Marzocco Espresso Machine

Programming Coffee Amount

Programming will save the **amount of water** (how much coffee is in the cup), not the time!
 We recommend using scales for this.

Programming from the **left** group is automatically copied to the other groups.

GB 5 X	LINEA PB X*	KB90*	STRADA AV*
			
			
<p>Press and hold the button you want to program for about 4 seconds, release once activated. «PRG» is displayed in the menu. Press button again once the desired amount is reached in the cup. «SAV» is displayed in the menu. ▶ Repeat for other buttons.</p>	<p>Hold button until the menu appears on the display.</p>		
			
	<p>Press button to scroll to the first menu point.</p>		
			
	<p>Press button again to enter the first menu point.</p>		
			
	<p>Press button again to activate programming mode.</p>		
			
<p>Press and release the button you wish to program to start and stop programming. ▶ Repeat for other buttons. <i>Every button can be programmed twice, with each a short and long (ca. 1.5 sec) push.</i></p>	<p>Press and release the button you wish to program to start and stop programming. ▶ Repeat for other buttons.</p>		
			
<p>Press button to end programming.</p>			
			
<p>Press simultaneously to exit the menu.</p>			

* For machines with integrated scales: Only flowmeter («pulses») programming (i.e. w/o scales).
 Machines must be set to «Pulses» in the menu under «Group Dose Settings» – «G X Dose Settings» – «G X Mode».
 For programming of the scales see manual.