Poststrasse 3 | CH-9403 Goldach T+41(0)71 277 95 80 | F+41(0)71 277 95 81 info@kialoa.ch | www.kialoa.ch

kialoa

La Marzocco Espresso Machine

Cleaning Instructions

Backflush machine with blind basket, ½ tsp. detergent and cleaning program.







press simultaneously

2. Backflush machine with clean blind basket and cleaning program.





press simultaneously

Remove shower head with screw, clean, tighten gently.





do, all parts stainless steel.

Clean portafilter and basket.



▶ no soaking necessary, water + sponge will

Clean group head (rubber seal) with brush.



6. Don't remove steam wand tip. Purge well, if necessary (or occasionally) heat up special detergent with water.





Clean drip tray and the machine body. Careful (!) if your machine has integrated scales.



Control water filter flowmeter.

8.

► It counts backwards, replace at «0» (spent) or when blinking (expired)!



Help:

- Find manuals and videos under product details online at kialoa.ch
- Shop for cleaning equipment and accessories at kialoa.ch
- In case of technical problems, for servicing, and replacing water filters please contact our local servicing partner.

servicing partner 071 277 95 82