

# Modbar *new* Pour-Over Startup Guide

## Select your configuration

One Pour-Over tap.....	2
Two Pour-Over taps.....	3
One Pour-Over tap and one Hot water tap .....	4

# One Pour-Over tap

## 1. First Startup and Heating

- Switch on the red button
- Display says "FIRST STARTUP" OFF. Press the encoder
- Display asks "Is the boiler full". Press the lever until water comes out
- You can then press "Yes"
- Switch the machine off and then back on
- The machine will start heating

## 2. Flow calibration

- Place a scale and a pitcher under the tap
- Long press the encoder to enter the menu, then enter Machine Settings
- Find "Flow Calibration" and press the encoder
- Follow the instructions to calibrate the water flow

## 3. Configure gateway

- Long press the encoder to enter the menu, then enter Machine Settings
- Find "Configure Gateway" and enable it. Press to confirm
  
- On your phone, download the La Marzocco app and activate bluetooth
- Add new device, then select the serial number corresponding to your machine
- Select Wifi network and enter its password
- Once the connection is complete you can disable "Configure Gateway" on the machine

# Two Pour-Over taps

**Note:** step 1 of this procedure will only be necessary until the next firmware update, where you will be asked to assign Tap 1 or Tap 2 on the first startup screen.

## 1. Assigning Tap 2

- Every tap is a “Tap 1” by factory default
- On your chosen “Tap 2”, keep holding down the encoder button and the lever at the same time, and then turn on the machine.
- Technical password is 3090
- Select “Tap 2” and wait for the display to reset.
- Restart the machine.
- You should see “Tap 1” and “Tap 2” appear on the displays as they load

## 2. First Startup and Heating

- Display says “FIRST STARTUP” OFF. Press the encoder
- Display asks “Is the boiler full”. Press the lever until water comes out
- You can then press “Yes”
- Switch the machine off and then back on
- The machine will start heating

## Flow calibration

- Place a scale and a pitcher under the tap
- Long press the encoder to enter the menu, then enter Machine Settings
- Find “Flow Calibration” and press the encoder
- Follow the instructions to calibrate the water flow

## 3. Configure gateway

- Long press the encoder to enter the menu, then enter Machine Settings
- Find “Configure Gateway” and enable it. Press to confirm
  
- On your phone, download the La Marzocco app and activate Bluetooth
- Add new device, then select the serial number corresponding to your machine
- Select Wifi network and enter its password
- Once the connection is complete you can disable “Configure Gateway” on the machine

# One Pour-Over tap and one Hot water tap

## 1. First Startup and Heating

- Switch on the red button
- Display says “FIRST STARTUP” OFF. Press the encoder
- Display asks “Is the boiler full”. Press the lever until water comes out
- You can then press “Yes”
- Switch the machine off and then back on
- The machine will start heating

## 2. Configuring the Hot Water Tap

- Long press the encoder to enter the menu, position yourself on Machine Settings and press the encoder for >5 seconds, until you’re asked to enter the password
- Technical password is 3090
- Find “Machine Config Settings”
- Number of Taps: 2
- Tap 1: Tap Pour-Over
- Tap 2: Hot Water
- Find “Back”, then find “Exit” to return to Home menu

## Flow calibration

- Place a scale and a pitcher under the tap
- Long press the encoder to enter the menu, then enter Machine Settings
- Find “Flow Calibration” and press the encoder
- Follow the instructions to calibrate the water flow

## 3. Configure gateway

- Long press the encoder to enter the menu, then enter Machine Settings
- Find “Configure Gateway” and enable it. Press to confirm
  
- On your phone, download the La Marzocco app and activate bluetooth
- Add new device, then select the serial number corresponding to your machine
- Select Wifi network and enter its password
- Once the connection is complete you can disable “Configure Gateway” on the machine

For any questions please contact [modbarsupport@lamarzocco.com](mailto:modbarsupport@lamarzocco.com)