






















La Marzocco Espresso Machine

Programming Coffee Amount

Programming will save the **amount of water** (how much coffee is in the cup), not the time!
 We recommend using scales for this.

Programming from the **left** group is automatically copied to the other groups.

GB 5	LINEA PB*	STRADA AV*
  Hold button until the menu appears on the display.	  Hold button until the menu appears on the display.	  Hold button until the menu appears on the display.
 Press button again, button starts blinking.	 Press button again to enter the first menu point.	 Press button again to enter the first menu point.
 Press and release the button you wish to program to start and stop programming. ▶ Repeat for other buttons.	 Press button again to activate programming mode.	 Press button again to activate programming mode.
 Press button to end programming and leave the menu.	 Press and release the button you wish to program to start and stop programming. ▶ Repeat for other buttons. <i>Every button can be programmed twice, with each a short and long (ca. 1.5 sec) push.</i>	 Press and release the button you wish to program to start and stop programming. ▶ Repeat for other buttons. <i>Every button can be programmed twice, with each a short and long (ca. 1.5 sec) push.</i>
 Press button to end programming.	 Press button to end programming.	 Press button to end programming.
 Press simultaneously to exit the menu.	 Press simultaneously to exit the menu.	 Press simultaneously to exit the menu.

* For machines with integrated scales: Only flowmeter («pulses») programming (i.e. w/o scales).
 Machines must be set to «Pulses» in the menu under «Group Dose Settings» – «G X Dose Settings» – «G X Mode».
 For programming of the scales see manual.