

STEP 01

Put unit with the top side on a table and unscrew 2 hex. bolts.



STEP 02

Insert the filter basket holder.



STEP 03

Push the lower clamp downwards until filter basket holder is firmly clamped between lower and upper clamp.



STEP 04

Fasten the 2 hex. bolts firmly.



STEP 05

Insert the filter basket holder and check if it properly clamped between both clamps. Of not repeat step 1-4.



STEP 06

Mount the power cable and fix the cable as is shown below.



STEP 07

Insert the drip tray.



STEP 08

Turn unit ON.

